





1




2


This screw is only for fixing "B" part,
you have to fix these 2 screws after
you assemble B part



3



5



4

